ITEM	Qty -041	Qty -043	Part Number	Description
1	Х		D3804-041	SKIDTUBE ASSEMBLY, 206 A/B LOW
2		X	D3804-043	SKIDTUBE ASSEMBLY, 206 A/B HIGH
5	1	1	D2600-1-160	EXTRUSION
6	1	1	D2646	AFT CAP
7	1	1	D2647	CAP
8	19	20	D2649	CROSS BOLT SPACER
9	6	8	D2651-1	PLUG
10	6	8	D2651-3	O-RING
11		1	D2654-3	WEB
12	1		D2654-1	WEB
13	1	1	D2680-041	NUT PLATE
14	2	2	D3286-1	DOUBLER
15	2	2	D3286-3	STUD
21	2	2	AN960JD10L	WASHER
22	1	1	AN960JD416	WASHER
23	2	2	CCR264SS3-3	RIVET
24	2	2	CR3212-4-03	RIVET
25	52	52	CR3212-4-04	RIVET
26	2	2	MS27039-1-08	SCREW
27	1	1	MS27039-4-06	SCREW

NOTES


- 1) MATERIAL: N/A
- FINISH: -CHEMICAL CONVERSION COAT PER DART QSI 005 4.1 -POWDER COAT WHITE (4.3.5.1) PER DART QSI 005 4.3
- 3) BLACK ANTI-SKID PAINT AS INDICATED TO 0.5 ABOVE LOCATION RIDGE PER **DART QSI 005 4.4**
- TOLERANCES ARE PER DART QSI 018 UNLESS OTHERWISE NOTED
- UNITS: INCHES UNLESS OTHERWISE NOTED
- BREAK SHARP EDGES: 0.005 TO 0.010 MAX
- **IDENTIFICATION: NONE**
- WEIGHT: 12.5 lb
- 9) WELD PER DART QSI 004
- 10) BENDING: DAMAGE TOLERANCE ON FWD BEND: THERE SHOULD BE NO VISIBLE WRINKLES IN THE BEND FROM THE GROUND TO A HEIGHT OF 5 INCHES ABOVE THE GROUND. IT IS ACCEPTABLE TO POLISH OUT GOUGES UP TO 0.020 DEEP IN THE BENT PORTION OF THE TUBE. A MAXIMUM REDUCTION IN DIAMETER OF 0.150" IS ACCEPTABLE IN THE BENT PORTION OF THE TUBE.
- 11) BOND WEB INTO OUTER TUBE WITH SIKAFLEX-241/-291 ADHESIVE PER DART QSI 015
- 12) INSERT D2651-1 PLUG C/W D2651-3 O-RING IN HOLES MARKED 'P' (BOTH SIDES OF TUBE)


DEO ATTACHED


NEW ISSUE МВ 08.07.07 Α REV. DESCRIPTION BY DATE DESIGN 92 DART AEROSPACE USA, INC DRAWN PORT HADLOCK, WA CHECKED DRAWING NO. REV. A D3804 SHEET 1 OF 5 APPROVED SCALE TITLE SKIDTUBE ASSEMBLY, 206A/B COPYRIGHT © 2008 BY DART AEROSPACE USA, INC 08.07.07


MFG. APPR. DE APPR.

PC ECN 09-538









DRAWING NO	. TITLE	REV. A	DART AEROSPACE LT	D D.E.O. NO.	SHEET NO.	SCALE
D3804	SKIDTUBE A	ASSEMBLIES, 206A/B	ENGINEERING ORDER	R D3804-A-1	SHEET 1 OF 1	NTS
DRAWN	W	CHECKED A.P.	MFG. APPR.	APPROVED	DE APPR.	
DATE 1	12.10.12	DATE 12.10.22	DATE 12.10.22	DATE (2-10.22	DATE 12-10.22	-

PURPOSE:

CHANGE C'BORED WELDED CROSSBOLT SPACERS TO SWAGED SPACERS

CHANGE:

PARTS LIST IS AMENDED AS FOLLOWS:


IS:

QTY	QTY		
-041	-043	PART NUMBER	DESCRIPTION
1	1	D2649	CROSS BOLT SPACER
18	19	D4720-1	SPACER




19 20 D2649	CROSS BOLT SPACER	

ADD SECTION H-H BELOW, WHICH IS THE SAME SECTION VIEW AS SECTION D-D OF DWG. C'BORED HOLES ARE NOW SWAGED PER SECTION H-H BELOW. FOR THE Ø0.375 HOLE THAT IS NOT C'BORED, WELD PER SECTION D-D OF DWG (SEE AMENDED DETAIL B FOR REFERENCE).



DETAIL B AMENDMENT TO DETAIL B NOT TO SCALE



SECTION H-H FOR Ø0.375 HOLES ONLY FOR HOLES THAT ARE CURRENTLY C'BORED ONLY

NOT TO SCALE

2. SWAGE TO Ø0.313 X 0.75 DP PER QSI 002

AFTER DRILLING AND BENDING ASSEMBLY PERFORM THE FOLLOWING FOR Ø0.375 HOLES THAT ARE **CURRENTLY C'BORED:**

- 1. INSERT D4720-1 SPACER, 18 PL (-041) OR 19 PL (-043)
- 3. TRIM / GRIND FLUSH PER QSI 002

COPYRIGHT © 2012 BY DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERNISSION FROM DART AEROSPACE LTD.